

미세먼지 측정기 (Aerosol Monitor)

간이측정기 성능인증 1등급 제품



Model : 8532

용 도(Applications)	특 징(Features)
<ul style="list-style-type: none"> 실내 및 대기 미세먼지 측정 미세먼지, 초미세먼지 농도 추이 및 조사 산업 및 위생 현장 조사 배출원 측정 및 에어로졸 연구 PM10, 2.5, 4, 1, Respirable 측정 	<ul style="list-style-type: none"> 1초 이내에 정확한 농도 측정 및 저장 기능 손잡이가 있어 현장 사용시 편리성 증대 컬러 터치 디스플레이로 작동하기 간편함 충돌판 방식(Impactor)으로 보다 신뢰성 있는 측정 배터리, 센서상태, 유량, 필터 등의 상태 표시기능

SPECIFICATIONS

Type	Handheld
Sensor Type	90° light scattering
Aerosol Concentration Range	0.001~150 mg/m ³
Particle Size Range	0.1~10μm
Resolution	±0.1% or 0.001mg/m ³
Zero Stability	±0.002mg/m ³ per 24hours at 10sec time constant
Flow Rate	1.4 ~ 3.0liter/min(3.0liter/min set at factory)
Flow Accuracy	±5%
Temp. Coefficient	+0.001mg/m ³ per °C
Optional Temp	0 ~ 50°C
Storage Temp	-20 ~ 60°C

Time Constant	User Adjustable, 1 ~ 60 sec.
Data Logging	5MB of on-board memory (>60,000 data points), 45days at 1min. logging interval
Log Interval	User Adjustable, 1 ~ 3,600 sec.
Screen	3.5 in. VGA color touchscreen
Battery	3600mAH Li-ion
Size (HWD)	125 x 121 x 316 mm
Weight	1.3kg / 1.5kg (with battery)

Battery information

3600 mAH Li-ion Battery Pack	Battery
Battery Runtime (hours)	Up to 6
Charge Time (hours) in DustTrak	4

CONFIGURATIONS

DustTrak II Handheld Aerosol Monitor	1 ea
Carrying case	1 ea
Rechargeable 3600mAH Li-ion battery	1 ea
Switching power supply w/ Universal plugs	1 ea
Trakpro data analysis software CD	1 ea
Zero filter	1 ea
USB computer cables	1 ea
Inlet caps	2 ea
10mm nylon Door-Oliver Cyclone	1 ea
Impactor Kit (with PM1, PM2.5, PM4, PM10)	1 kit
Impactor plate (2) and impactor oil(5ml)	1 ea
Sample extension tube, 1m	1 ea
Sheath air HEPA filter	8 ea
Filter removal tool	1 ea
Screwdriver	1 ea
Operation service manual(영문, 한글)	1 ea