

Water Level Meter



Model : SP

용도

Applications

- 지하수, 급수탑 및 Borehole 등의 수위 측정

특징

Features

- 부저 및 램프로 수위 감지 확인
- Tape의 늘어짐을 막고 손상을 최소화
- mm 단위의 정확한 측정 가능
- 30m Tape이 0.6kg으로 경량화 실현

SPECIFICATIONS

Power source	9V Battery
Dimensions	H 340mm x W 250mm x D 200mm
Reel weight	2.25kg
Tape weight per 30m	0.6kg
Reel diameter	215mm
Probe diameter	16mm
Probe length	190mm
Tape length according to model selected	30m, 60m, 100m
Operating temperature Reel	100 °C
Operating temperature Probe	150 °C
Reel seal	Silicone and epoxy resin
Reel	Nylon disc, hub and electronic panel
Main bearing	Delrin
Frame	Polyurethane powder coated mild steel
Fitting	Stainless steel (where possible)
Probe	Stainless steel and Teflon®
Electronic	Epoxy encapsulated
Tape	Linear low density polyethylene, with two 7-strand stainless steel conductors with Kevlar reinforcement
	Scale printed in black; unitary numbers in red
	Graduations: Metres, centimetres, millimetres
	Unitary metres in red, other markings in black

STANDARD DIPMETER AVAILABLE LENGTH

30m Standard Dipmeter	1 set
60m Standard Dipmeter	1 set
100m Standard Dipmeter	1 set